




## GripLoc™ Release Tool Instructions

See package Label for applicable pipe-tool size

**WARNING: Be sure system is OFF  
and PRESSURE RELEASED**

GLRT-3-1015



Press tool in around pipe at end of GripLoc™ fitting. Due to Spears® High-strength Gripper Ring, tool may need to be tapped in with a rubber mallet to fully release. Carefully pull pipe from Griploc™ fitting. Fitting and pipe not recommended to be reused if any damage occurs while removing fitting. Check O-ring and pipe surface for damage.

Spears® Manufacturing Company • 15853 Olden St • Sylmar, CA 91342 • 818-364-1611